



12-oz. Can Drill Template

The solid lines are a cut lines. Pasting the cut line flush to the bottom edge of the top can crimp puts the targets exactly 3/4" below the top edge of the can. You'll need to cut out both strips to go all the way around the can. Punch sixteen centers for 1/2" holes.

Cut line — paste this edge to bottom of top 12-oz can crimp

+ + + + +

Cut line — paste this edge to bottom of top 12-oz can crimp

+ + + + + + + + + + + + + + +