



Paint Can Drill Template

Cut the strips free at the solid lines. Pasting the bottom cut lines flush with the top of the paint can's bottom crimp puts the targets exactly 3/4" above the bottom of the can. You'll need to cut out both strips to go all the way around the can. Keep your first target around 1/2" away from the can seam. Punch centers for twelve 1/2" holes. Use glue stick or spray mount to stick the strips to the can. It's best to pull off the strips and clean up the glue after you've punched and before you start drilling, as the drill may heat up and cook the glue to the can.

TURN OFF PRINT SCALING BEFORE PRINTING!

